



Refer to the IVY manual for part values and configuration.

R21 and R22 can be jumpered for driving headphones etc. They are there to make it easier to drive a capacitive load.

C13-16 Are normally omitted. Only use in the "Hybrid" configuration for Buffalo

Twisted Pear Audio	IVY A flexible I/V converter/filter with balanced to single ended conversion.			
	Russ White			
DIY Use Only	SIZE	FSCM NO.	DWG NO.	REV 2.0
Copyright 2008	SCALE			Sheet 1